



PREVENTATIVE MAINTENANCE

**Preventative maintenance is required every 3 months
by a qualified service technician:**

- ✓
Check temperatures
 - Check the filter is clean
 - Check drain for damage and/or blockages
 - Check and clean the condensate tray
 - Check and clean the condensate drain lines
 - Check condenser fan motors
 - Check adequate airflow to compressor
 - Check evaporator fan motors
 - Defrost evaporation coil and check fins for any damage or movement
 - Clean condenser coil with compressed air
 - Check and clean air grilles
 - Check LED lighting and diffusers
-

**Once the preventative maintenance has been
undertaken, update the cabinet servicing record.**



**Trusted.
For Life.**